




Spare Part List

Volaris S2, S3



1	Dynamic handle S3 R	3000011	10	Rear fork R	3200001
1	Dynamic handle S3 L	3000012	10	Rear fork L	3200002
1	Dynamic handle S2 R	3000021	11	Rear wheel cpl R	3221001
1	Dynamic handle S2 L	3000022	11	Rear wheel cpl L	3221002
2	Lock handle with axle	4017940351	12	PSH M6x48	4017930075
3	Screw M6x8	4017930094	13	Furniture nut	4017930074
4	Wire S3	4017930033	14	Screw MC6S M6x40	4017930079
4	Wire S2	4017930034	15	Locking nut M6	4017930071
5	Lock handle with axle and bolt	3000300	16	Brake spring	4017930037
6	Wheel with bearing and bushings	3021000	17	Seat	4017911281
7	Front fork	3100000	18	Seat pin	4017940650
8	Front wheel cpl R	3121001	19	Lifting device upper part	4017910700
8	Front wheel cpl L	3121002	20	Load shelf incl lifting device lower part	4017910600
9	Screw RXS ST 2,9x8	4017930080	21	Holder loadshelf	4017910070
			22	Screw KX-PTPhil K40x20	4017930093
			23	Folding mechanism cpl	4017910020